



PROPERLY INSTALLED STRAW BALE
(CROSS-SECTION)


1. EXCAVATE THE TRENCH MIN. 4" DEEP.



2. PLACE AND STAKE STRAW BALES.



3. BACKFILL AND COMPACT THE EXCAVATED SOIL.



NOTES:

1. SEDIMENT MUST BE REMOVED DAILY.
2. ANY SECTION, WHICH HAS BEEN UNDERMINED OR TOPPED, MUST BE IMMEDIATELY REPLACED.
3. ENDS OF STRAW BALES MUST BE INSTALLED TO PROHIBIT RUNOFF FROM BEING ALLOWED TO FLOW AROUND ENDS.

REVISIONS

MISSOURI AMERICAN WATER STANDARD
CIVIL
TEMPORARY STRAW BALE
SEDIMENT BARRIER DETAILS

MISSOURI AMERICAN WATER
ST. LOUIS, MO. 63141

MISSOURI AMERICAN WATER ENGINEERING
727 CRAIG ROAD
ST. LOUIS, MO. 63141

DRAWN BY KKM
PROJECT ENG'R
APPROVED

DATE 11-13-08
PROJECT IP


AMERICAN WATER
USE DIMENSIONS ONLY
SCALE N.T.S.

USE APPROVED DRAWINGS ONLY
FOR CONSTRUCTION PURPOSES

0201-0601-SD67